



We Are Dispensers

Label Dispensers

VHB Application

Non-Adhesive Cutters

Wire Harnessing
Heat Shrink Tubing

APPLIANCE

MANUFACTURING

PACKAGING

Die-Cut Gaskets

Safety Seal

AUTOMOTIVE

Barcodes

Promotional Labels

pharmaceutical

ELECTRONICS

SOLAR & WIND POWER

Battery Manufacturing

Parts Assembly

FOOD & BEVERAGE

RFID

Tape Dispensers

MEDICAL

LD8000 Series



LD8025 LD8050 LD8100



START International
4270 Airborn Drive, Addison, TX 75001, U.S.A.
Tel 1.972.248.1999 • Fax 1.972.248.1991 • service@STARTInternational.com
www.STARTInternational.com



We Are Dispensers

CONTENTS

Read this user's manual before use to ensure proper operation. Keep the manual on hand for reference in case there is a problem.

| | |
|-------------------------|--------|
| Warranty Information | Page 2 |
| Maintenance | Page 3 |
| Exploded View | Page 3 |
| Features | Page 4 |
| Notes | Page 4 |
| Repair Policy | Page 4 |
| Specifications | Page 4 |
| Set-up & Operation | Page 5 |
| Safety | Page 6 |
| Photosensor Adjustments | Page 7 |

WARRANTY POLICY FOR LD SERIES LABEL DISPENSERS

START International warrants all parts on LD8000 series label dispensers against defects in design, materials and workmanship for a period of 1080 days. Labor to replace defective parts will be performed at no charge for the first 360 days after date of purchase.

Warranty does not cover transportation costs.

Our sole obligation under this warranty is limited to repair, replacement or credit of the purchase price, at our option, for the machines listed above, which do not perform properly the function for which they were designed.


Warranty repair is contingent upon our examination and determination that alleged defects have not been caused by misuse, abuse, improper installation or application, repair, alteration, accident or neglect in use, storage, transportation or handling.

The above warranty and remedy constitutes START International's sole liability hereunder and are in lieu and exclusive of all other warranties and remedies expressed, implied, or statutory, including, but not limited to, those of merchantability and fitness for a particular purpose.

MAINTENANCE

Turn machine off when not in use. Remove liner material from take-up hub at approximately 3" in diameter or if motor appears to be straining. Do not operate machine without covers in place. Do not operate if inspection reveals a damaged power or sensor cord.

EXPLODED VIEW





We Are Dispensers

FEATURES

- Will dispense butt-cut and die-cut material.
- Adjustable photosensor for pinpoint accuracy.
- Handled lock rod makes scrap removal easy.
- No tools required for adjustment.
- Hanging capability with optional LDHANGER. (Needs to be secured properly)

NOTES

- Keep strip plate free of adhesive build-up.
- Clean photosensor with compressed air or dry cloth.
- Do not drop the dispenser or subject it to heavy shock.
- Turn off machine when not in use.

REPAIR POLICY

Contact START International to determine the nature of the problem.

Supply START with the following information:

1. Who the unit was purchased from.
 2. Model number and serial number.
 3. If available, date purchased and copy of invoice or packing slip.
- START will issue a RMA (Return Merchandise Authorization) for repair.
Return machine to START, insured and prepaid.
START will notify the customer if there is a repair charge.

SPECIFICATIONS:


| Model# | LD8025 | LD8050 | LD8100 |
|----------------------------|---|--|--|
| Liner Capacity Width | .25" to 5" (6mm to 127mm) | .25" to 5" (6mm to 127mm) | .25" to 5" (6mm to 127mm) |
| Label Length | .125" to 12" (.50mm to 305mm) | .50" to 12" (.50mm to 305mm) | .50" to 12" (.50mm to 305mm) |
| Roll Capacity | 12" (305mm) | 12" (305mm) | 12" (305mm) |
| Feed Speed* | 2"/sec (5.1cm/sec) | 3.9"/sec (10cm/sec) | 7.8"/sec (19.8cm/sec) |
| Dimensions Inches | 14.4 (L) x 11.9 (W) x 10.4 (H) | 14.4 (L) x 11.9 (W) x 10.4 (H) | 14.4 (L) x 11.9 (W) x 10.4 (H) |
| Centimeters | 36.6 (L) x 30.2 (W) x 27.7 (H) | 36.6 (L) x 30.2 (W) x 27.7 (H) | 36.6 (L) x 30.2 (W) x 27.7 (H) |
| Weight | 6.9 lbs (3.2kg) | 8.75 lbs (4.0kg) | 8.75 lbs (4.0kg) |
| Electrical Requirements | 100/115V AC 0.75A 60Hz, 220-240V AC 1.8A 50Hz CE available) | 100/115V AC 0.75A 60Hz, 220-240V AC 1.8A 50/60Hz CE available) | 100/115V AC 0.75A 60Hz, 220-240V AC 1.8A 50/60Hz CE available) |

SET-UP INSTRUCTIONS

*Machine must be unplugged from power supply for Steps 1 to 7.

1


Load Label Roll



- A: Insert core holders (2) into each side of your label roll
- B: Slide label roll onto reel hanger bar
- C: Rotate the large hub lock **Gently** clockwise until it locks into place


2

Feed Labels



3


Feed Label Liner over Strip Plate



- A: Feed label liner between brush and strip plate

4

Separate Liner over Top of Strip Plate



- A: Feed label liner over strip plate separating the liner from the label




We Are Dispensers

SET-UP INSTRUCTIONS

5


Remove lock rod and Secure liner



- A: Slide lock rod off of take-up hub
B: Secure label liner onto take-up hub and
C: Slide lock rod back on to take-up hub with
2-3" (50-75mm) of liner beyond the lock rod.

6


Adjust Brush Pressure



- A: To apply the proper amount of tension for
proper label feeding and detection; loosen
brush wing screw and press down to increase
tension, then tighten screw.

7


Adjust Label Sensor



- A: Loosen wing screw, then adjust sensor plate.
B: Point sensor towards the top edge of the label.
C: Tighten wing screw to secure sensor in place.

8

Plug In & Turn On



- A: Connect power cord (in back)
B: Turn power switch (on back) to turn
on machine

Now you're ready to roll.



We Are Dispensers

ADJUSTMENTS

Hold Down:


Using the upper thumbscrew on the side of the machine, adjust the hold down for tensioning. For best results, labels should be pressed firmly against the strip plate. However, if the labels are held too tightly, they will cause excessive drag on the motor.

Photosensor:


The photosensor can be adjusted in any direction by using the lower thumbscrew on the side of the machine and the thumbscrew underneath the photosensor bracket. Loosening the thumbscrew on the side of the machine allows the photosensor to move in and out. This is used to set the overhang distance of the label over the strip plate. The thumbscrew underneath the photosensor bracket is used to swivel the sensor along the front of the strip plate. When the label is being fed the correct distance, lock the bracket in place. If there are 2 or more labels across, align the photosensor with the last label to be removed. When these screws are locked in place, the machine is set.

Positioning of Photosensor

Incorrect



Correct



Sensor sees front edge of label